STEP 1:

Slip wristband tether into FlexGuard's back end.

STEP 2:

Slide scanner into Flexguard sleeve, nose first.

STEP 3:

Adjust sleeve to fit snugly and evenly all around the scanner.