



Barcode Scanner Charging Cradles

The Charging Cradle is designed to recharge and provide easy storage of the DuraScan scanners. When not in use or in between scanning sessions, scanners can charge on the cradle, set up in multiple ways. A multi-angle mounting bracket sets the cradle in different positions on a flat surface, or attaches to a wall for optimal convenience. Power LED indicates the cradle is ready. Simply set the scanner in the cradle, push down and the scanner begins charging. For additional convenience, the cradle is designed to charge scanners without having to remove the wrist strap.

Hardware Features

- Designed to charge DuraScan barcode scanners and DuraScan RFID Reader
- Built-in latch securely holds DuraScan products in place for charging
- Flexible configuration options:
 - Lay flat on table
 - Stand upright at an angle
 - Mount to wall
- Rubber grips on bottom of cradle prevent sliding
- Charging Cradle LED indicates when cradle is “On” and connected to power

Technical Specifications

- Compatible with any AC or DC adapter with 5V output at 1.4-2.0A and 4 mm barrel connector
- Dimensions:
 - Charging cradle only: 6.3 in x 2.4 in x 1.3 in (15.9 cm x 6 cm x 3.2 cm)
 - Charging cradle with bracket installed: 3.9 in x 5.7 in x 2.4 in (9.8 cm x 14.5 cm x 6 cm)
- Weight (excluding AC adapter):
 - Charging cradle only: 4.4 oz (125 g)
 - Charging cradle with bracket: 5.7 oz (162 g)
- Warranty: 1 Year

Included Items

- Charging Cradle
- Charging Cable
- Mounting bracket and 2 mounting screws